### SM 8000 USER MANUAL


#### SpaceMaster Series Photoelectric thru beam sensors

Electrical Dat	ta					
			DC		AC	
			Transmitter	Receiver	Transmitter	Receiver
Supply Voltage			10-30 V dc		20-250 V ac	
Voltage ripple			+/- 15%		-	
Reverse polar	ity prote	cted	Yes		-	
Short circuit protected			-	Yes	-	
Current consumption			15 mA	5 mA	3 mA	2 mA
Max. output load			- 12	20 mA/30 V dc	-	200 mA
Environmental Data Temperature, operation Sealing class		'n	-20 to +60 °C IP 67			
Approvals		ac	(E c <b>A)</b> us			
, pprovidio		dc	CE			
Available Mo	dels					
	Мо	del	Supply Voltage	Output	Output Mode	Sensing Range
	SMT	8000	10-30 V dc	-	-	20 m
Transmitter	SMT	8600	20-250 V ac	-	-	7 m
		600H	20-250 V ac			20 m (*)


		SIVI 1 0000H	20-200 V ac	-	-	20111()
		SMR 8400		NPN	Light/dark	0-7 m,
Receiver	SMR 8500	10-30 V dc	PNP	Light/dark	adjustable	
	SMR 8420		NPN	Light/dark	0-20 m,	
	SMR 8520		PNP	Light/dark	adjustable	
	SMR 8800	20-250 V ac	SCR	Light/dark	7 m fixed	
	SMR8820	20-250 V ac	SCR	Light/dark	20 m fixed (*)	

## (\*) Used together

#### Illustration





DC Models




Connection Wiring Diagrams

Transmitters






SMR 84XX Transistor NPN



SMR 85XX Transistor PNP



WARNING: DO NOT CONNECT THE SMR WITHOUT A SERIAL LOAD

SMT 8600

Website: www.telcosensors.com E-Mail: info@telcosensors.com Made in Denmark



SCR

Warning This device is not to be used for Personnel Protection in Machine Guarding Safety applications. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel machine guarding stand-alone safety applications.

#### Connection Wires/Pins Cable 3 pin, M8 plug 4 pin, M12 plug Blue & Brown AC supply Supply + Brown Pin 1 Pin 1 Supply -Blue Pin 3 Pin 3 Control/Output Black Pin 4 Pin 4 4 •

Sensor plug

#### Mounting & Alignment

Mounting & Alignment

- Mount the transmitter and receiver sensors facing each other. Make sure the distance between the sensors does not exceed the specified sensing range of the system. 1
- Align the sensors by moving, either the transmitter or receiver sensor, horizontally and vertically until the output is: - Deactivated when no object is present. (Dark operated) 2
  - Activated when no object is present. (Light operated)
- Fasten the transmitter and receiver sensors securely using the enclosed locking nuts and/or a mounting bracket. 3
- Avoid acute angles on cable close to sensor.

# Adjustments

# **Output Mode Selection**

The output mode can be selected via an integral switch on the receiver sensor. Refer to Output Logic table for output mode reference.

Light Operated (N.C.)	Enables the output to be inactive when there is an object present.	Turn potentiometer to full clockwise position
Dark Operated (N.O.)	Enables the output to be active when there is an object present.	Turn potentiometer full counter clockwise position

#### Output Logic

	Output Mode	Output status	Yellow LED		
Detection			DC models	AC models	
				#1	#2
Object absent	Deals exercised (NLO.)	0	Off	On	Off
	Dark operated (N.O.)	Open	Oli	On	Oli
		<u>.</u>	•	0″	•
	Light operated (N.C.)	Closed	On	Off	On
Object present	Linkt on costs of (NLO.)	0	0"	0	0"
	Light operated (N.C.)	Open	Off	On	Off
				~ "	
	Dark operated (N.O.)	Closed	On	Off	On

#### Sensitivity Adjustment

Test Input

Maximum sensitivity can be used for most applications and is advised for applications with contaminated environments. Increase the sensitivity to maximum by turning the potentiometer, on the receiver sensor, to full clockwise position

Sensitivity adjustment may be required in applications where objects to be detected are small or translucent. Proceed with the following steps:

- Start with the sensitivity at maximum by turning the potentiometer to full clockwise 1 position. 2 Select target object with smallest dimensions and most translucent surface. 3
- Place target object between transmitter and receiver sensors. Decrease the sensitivity by turning the potentiometer counter clockwise until the
- 4 output changes.
- 5 Remove target object. Check output status has changed.

#### DC models only

DC models only

The transmitter can be externally disabled and enabled, via the control wire, for test purposes. The test input requires the control wire to be connected to - (negative) supply wire. Make sure no object is present in the detection area when transmitter is disabled for test. When the transmitter is disabled, the receiver should change output.

Enable transmitter	Open (off) control switch (connected to + , or not connected)
Disable transmitter	Close (on) control switch (connected to -)

Note: If the test input is not to be used, it is recommended to connect the control wire to + supply wire.

> V 1.1 Part Number: 0666220871 April 2019 edition Telco A/S reserves the right to make changes without prior notice



Sensor plug